

SFS

UNIQUE TÜV-APPROVED SELF-VULCANIZING TUBELESS REPAIR SYSTEM

- Automatic vulcanization due to road surface friction
- No filter or adhesive necessary
- Adapts itself to any kind of hole or cut.
- Permanent repairs on tread up to 9 mm.
- Ideal solution for steel-belted tyres.
- Easy to use and time saving - dismounting unnecessary
- May be applied under all conditions - solid.
- Can be used on tyres of both passenger cars and trucks and heavy vehicles.



NOTICE

All information including images are given with the greatest care. Still, it is appropriate to users regardless of the test the suitability of each product for their own purposes. Novatio is not liable for the completeness and accuracy of information and refuses warranty for your specific use. The guarantee, which Novatio products provide, relates only to the standard conditions of sale of this product. In no case Novatio can be held responsible for incidental damages, or damages for improper use or sale of the product to another customer.

SAFETY SEAL - SAFETY SEAL PLUS

GENERAL INFORMATION

SAFETY SEAL is the only TÜV approved repair system for all tubeless tyres, even for Flat Tyres and Pax tyres. It is







the ideal solution for steel belted tyres.

SAFETY SEAL PLUS is a self-vulcanising liquid buy! rubber for inner tubeless tyres.

TECHNICAL INFORMATION AND PACKAGING

APPLICATION AND USE

- This seal does not contain any harmful or environmentally unfriendly components. Follow the instructions carefully. When the repair has been completed, carry out an inspection after approximately 200 km.
- 1. Determine the location of the damage. Remove the damaging object and note the angle where the object penetrated. If the angle of the damage is difficult to ascertain, place the needle in the hole alone to determine the angle.
- 2. Pull the cord through the eye of the needle until the cord sits in the middle of the needle.
- 3. Stick the cord into the hole. To do this, use constant pressure until half of the needle holder touches the tyre. Watch out: if a small hole has to be repaired, it is advisable to stick the needle into it first to clear out the hole.
- 4. Pull the needle handle straight out. Cut away superfluous material. Pressurize the tyre again. The tyre is ready to use.

Article nr	Name	Content	Section
			
			



TOOLS

WWW.TECH-MASTERS.EU

